

Benzing M1

How to “couple” & “uncouple” pigeons at the home loft

Owners of the newer Benzing M1's (V2.21 or later) or those who have had their earlier models updated by Kevin Clark or Benzing, can couple their own pigeons at the home loft without the use of a computer or the Club System.

To enable the coupling at the loft to take place the pigeon ring details need to be stored in the M1 first. ***That process is not covered by these instructions.***

1. Connect the M1 to the loft antenna and power it up the same as you would do on race days.
2. Press the “Menu” green button
3. Press the “Pigeon” green button
4. Press the “Change” blue button
5. Press the “Coupling” yellow button
6. Press the “New” blue button. *NB. If your M1 does not display the “New” button it cannot be used to couple at the home loft and will need to be updated by Kevin Clark if you want this feature.*
7. Select the pigeon you wish to couple, by using the up-down buttons, from the displayed list of uncoupled pigeons.
8. Press the “Tick” button once you have located the bird to be coupled.
9. The M1 will display, “*Hold the eRing over your loft antenna*”, do that and.
10. The bird is now coupled and its ring details can no longer be seen in the list of **uncoupled** birds.
11. Place the eRing on the leg of the selected pigeon and its now ready to race or train using the M1.
12. To uncouple a pigeon from its eRing. At item 6 above, select “Delete” rather than “New” and select and delete the pigeon coupling from the list. *Tip:- it is better to delete the coupling rather than deleting the ring details of a pigeon in your M1. That way if the bird returns later you can re-couple the bird as described above.*
13. Always press the “Home” button (picture of a house) when finishing any process with the M1.